

LUX Products Corporation – Model # CV100

Clear View Electronic Timer

This Timer has 4 functions that can be activated by touching the see thru LCD panel to display Clock/Temperature/Date/ or Timer mode.

SETTING THE TIME

1. Press LCD panel until it goes to time mode.
2. Press SET and hold on 2 sec, the hour will blink, press ▲ or ▼ button to change hour setting.
3. Press and hold ▲ or ▼ button to advance the hour at a faster rate.
4. Press SET again, the minute will blink, press ▲ or ▼ button to change minute setting.
5. Press and hold ▲ or ▼ button to advance the minute at a faster rate.
6. Press SET to complete time setting. If more than one minute passes and no button is pressed, time setting will be completed at the last setting.
7. After time setting is completed, press ▲ or ▼ button to choose 12-hour or 24-hour time formats (when in the 12-hour time mode, PM is indicated on the display).
8. Slide TIME MODE switch to ON position, the display will auto return back to Time mode if you do not touch the LCD display for 10 seconds.

SETTING THE ALARM TIME

1. Press LCD panel until it goes to TIME display mode.
2. Press ALARM button, AL symbol will appear on the screen. If ten seconds goes by without any further button presses, AL symbol will disappear from the screen.
3. Press SET and hold for 2 sec, the hour will blink, press ▲ or ▼ button to change the alarm's hour setting.
4. Press SET again, the minute will blink, press ▲ or ▼ button to change the alarm's minute setting.
5. Press SET to complete alarm time setting.
6. Press ALARM button and hold for 2 sec. to act ALARM ON, the bell symbol will appear on the clock face.
7. Press ALARM button and for 2 sec. again to turn the ALARM OFF, the bell symbol will disappear from the screen.
8. When reaching the set alarm time, the Bi-Bi sounds two minutes then auto shut, or press any button to stop alarm sound.

TEMPERATURE DISPLAY

1. Press LCD panel until it goes to TEMPERATURE display mode.
2. Press ▲ or ▼ once to change Centigrade or Fahrenheit.

SETTING THE DATE

1. Press LCD panel until it goes to DATE display mode.
2. Press SET and hold for 2 sec. the year blink, press ▲ or ▼ to change year setting.
3. Press SET, the month blink, press ▲ or ▼ to change month setting.
4. Press SET, the day blink, press ▲ or ▼ to change day setting.
5. Press SET to complete date setting.

SETTING TIMER

1. Press LCD panel until it goes to TIMER display mode.
2. The screen will show 60.00 (60 minute) pre-programmed setting for the first time. The maximum count down time setting is 180.59 (180 minute and 59 second).
3. To Start or Stop the count down function, press ▲ or ▼.
4. To reset timer, press ▲ or ▼ to stop the count down then pressing SET, the minute blink, press ▲ or ▼ to change minute setting.
5. Press SET again, the second blink, press ▲ or ▼ to change second setting.
6. Press SET to complete Timer setting then press ▲ or ▼ to start count down.
7. When Timer counts down to 00.00, the screen display at TIMER face and "Bye-Bye" sounds up for one minute. Press any button to stop alarm before the one minute limit.
8. The timer will retain in memory the last setting that you used.

CHANGING THE BATTERY

1. If the display is not clear, the battery should be replaced.
2. Pull battery door tab on the bottom of the clock and remove the door.
3. Insert one AAA battery according to polarity indicated on the battery compartment.
4. Close the battery door.