

Lux Products Cross Reference Chart
Single Stage Cooling & Two Stage Heating Heat Pumps
Not using Common Wire

HEAT PUMP SYSTEM NO COMMON TERMINAL	NEW THERMOSTAT AND CORRESPONDING TERMINALS							TAPE OFF NOT USED		
	E	G	Y	R	O	W2	B	C	L	
ARCO / Friedrich	X2	G	Y	RC		W2	B	C	L	
ARCO / Snyder General	E	G	Y	R	O	W1		C	X	
BARD	E	G	Y1	R		W2	B	X	L	
BARD, HP, WH, MHP, HPQ	E	G	Y	R		W2	W1	X	L	
BDP / BRYANT	E	G	Y	R	O	W1		C	F	
CARRIER	E	G	Y	R	O	Y1		C	L	
CARRIER 5Q	to W2	G	Y, W1	R	O	W2		C	L	
CARRIER 50Q, QT382	E	G	Y	R	O	W2		C	L	
COLEMAN		G	Y	RED	V	W2		BLCK		
GE BAY	X2	G	Y	R	O	W		B		T
HEIL-QUAKER / Whirlpool		G	Y	R	O	W		B		
JANITROL / Goodman	E	G	Y	R	O	W2		C		
LENOX TYPICAL HP6		F	M	V/VR	R	Y		X		
LENOX HP8	E	F	M	V/VR	R	Y		X		
LENOX HP9, 10	E	F	M	V/VR	R	Y		X	L	
LENOX HP16, 18, 19	E	F	M	V/VR	R	Y		X	L	
MAGIC CHEF PE	E	G	Y	R	O	W		C		
RHEEM / RUUD	E	G	Y	R		W2	B	X	L	
SNYDER GENERAL H-R811/Y594R1375		G	Y	R	O	W1		C		
TRANE	X2	G	Y	R	O	W		B	F	T
WEATHERKING		G	W1	R	Y1	E		C		
WESCO	E	G	W1	R	Y1	W2		C		
WESCO / ADDISON	E	G	W1	R	O			X		
WESTINGHOUSE H50	E	G	Y	R	O	W		X	L1	
WESTINGHOUSE HE		F	C	V/VR		H2	Z	X		
WHITE RODGERS	E	G	Y	R	O	W2		C	L	
WHITE RODGERS	E	G	Y	R	O	W2		X1		
YORK		G	Y	R	O	W		B	X	

Important: Use either the B or O terminal, never both.

For use with Models: PSDH105, DHP2110, LHP750*, PSDH121*, PSPH521*, HP2110, PSPH605
 Thermostats with (*) the COMMON wire can be wired to the C terminal. Thermostats without the (*) DO NOT
 USE COMMON, tape it OFF.